

IMPORTANT SAFEGUARDS

WHEN USING ELECTRICAL APPLIANCES,
ALWAYS OBSERVE BASIC SAFETY
PRECAUTIONS, INCLUDING THE FOLLOWING:

1. Failure to follow the instructions may cause irreparable damage and the manufacturer is not liable for the consequences.
2. During cold winter weather, use the product at room temperature to prevent potential product failure or safety issues caused by condensation on the surface.
3. Avoid exposing the product to high temperatures or direct sunlight, as this may cause aging or discoloration.
4. Only wash the bottle and its accessories to prevent unexpected damage.
5. Do not hang the power cord over the edge of the table or workbench where the product is placed.
6. Avoid placing the product on the edge of the table, to prevent potential vibration.
7. If you need to open the top cover while the machine is in operation press "Pause" first.
8. When the spray arm is in operation, opening the top cover directly and quickly may cause hot water to spray out and cause harm.
9. If abnormal phenomena (such as a burning odor) occur during use, stop the operation and immediately unplug the device.
10. Ensure you unplug the product after use.

11. Certain conditions (e.g,higher altitude, or lower ambient temperature) may affect the maximum operating temperature, potentially impacting the product's sterilization function.
12. Before moving or storing the product, remove the power plug and wait for the product to cool. Turn off the product and disconnect the power supply before replacing accessories or touching moving parts during use.
13. Do not use accessories or detergents from other manufacturers; otherwise, the warranty on this product will be void.
14. Use pure water or water with low hardness; otherwise, scale may affect the washing quality of the bottle and its accessories, as well as the overall effectiveness and lifespan of the product.
15. The use of non-specific detergents is prohibited. Using detergents not specified for this product may cause product malfunction, damage, or safety problems.
16. Residue from milk powder is easier to clean than substances such as rice paste.
17. Clean any remaining milk powder before placing it into the main machine, to avoid affecting the washing quality.
18. This product is for home use only.
19. Keep children away from this product . If detergent comes into contact with the skin or eyes accidentally, rinse thoroughly with clean water and consult a doctor immediately. Cut up plastic bags to prevent children suffocation.
20. It is not recommended for use by individuals who are not in good physical health, have sensory or mental disorders, or lack of relevant experience and

knowledge, to avoid unexpected losses.

21. If the product is faulty and the fault cannot be resolved according to the instructions, contact the manufacturer's after-sales service and professional maintenance personnel to solve the problem. It is prohibited to disassemble and repair the product yourself. If the power cord is damaged, it must be replaced by a professional from the manufacturer, its maintenance department or, a similar department to prevent potential hazards.
22. Avoid using power strips to prevent overheating of the contact part of the plug due to poor contact.
23. Insert it into a grounded socket and ensure a secure connection.
24. Before connecting the product to the power supply, check if the product voltage matches the power supply voltage.
25. Do not plug in or unplug the power plug with wet hands.
26. It is prohibited to move the machine during the working period. If not used for an extended period, power should be turned off.
27. During or shortly after operation, do not touch the heating plate, the area around the vent, inside the shelf, etc., to prevent injury.
28. If the machine needs to stop working in an emergency, press and hold the 'power' button, wait for the drainage to stop, and then unplug it.
29. Only add water at normal temperature to the tank. Adding hot water may cause damage to the machine.
30. Do not directly add water to the washing cavity of the machine, as it may lead to abnormal consequences.
31. There is an air inlet at the bottom of the product; please do not block it.