


Quick Start Guide


Package Contents



- 1 Motorized Mini-Brush
- 2 Telescopic Wand
- 3 Disposable Dust Bag (Complimentary gift)
- 4 2-in-1 Cleaning Head
- 5 User Manual
- 6 Auto-Empty Dock (With a power cord)
- 7 Multi-Surface Brush
- 8 Main Unit


Installation

Cleaner Heads



Main Unit and Auto-Empty Dock

Push the main unit on the dock in a downward motion as shown until it clicks into place.




Note:

- Extend the telescopic wand when using the main unit, and retract the wand when placing it on the auto-empty dock.
- Before putting the machine back on the auto-empty dock, ensure that the motorized mini-brush is removed from the main unit.

Brush Head Roller Removal


Multi-Surface Brush

1. Place the cleaner head as shown. Grab the tab on the end cap and turn counterclockwise to the unlock position.
2. After cleaning, slide the roller back into the cleaner head and turn the tab clockwise until it clicks into place.



Motorized Mini-Brush


1. Rotate the end cap counterclockwise to the unlock position to remove it and slide the roller out of the cleaner head.
2. After cleaning and drying, turn the end cap into the locked position. Ensure the roller is installed securely.



Instructions for Use

Start Cleaning

To start vacuuming, press . The screen will turn on. By default, the MED mode is used.




Note: To stop vacuuming, press .

Routine Maintenance

Main Unit


Use a soft and dry cloth to wipe the main unit. Do not rinse it. Disconnect the power before cleaning.

Dust Bin and Filter Cartridge Module




Cautions

Do not vacuum liquids or rinse the main unit or cleaner head to avoid damaging the electrical components inside.



* For illustration purposes only. The actual product may vary.
* Read the user manual carefully for more details about this product.



Scan this QR code for more languages.
Scannez ce code QR pour accéder à d'autres langues.
Scannen Sie diesen QR-Code für weitere Sprachversionen.
Scansionare il codice QR per altre lingue.
Escanee este código QR para acceder a más idiomas.
Scan deze QR-code voor meer talen.
Zeskanuj ten kod QR, aby uzyskać więcej języków.
Skann denne QR-koden for flere språk.
Skanna denna QR-kod för fler språk.
Digitalize este código QR para mais idiomas.
Skannaa tämä QR-koodi saadaksesi lisää kieliä.
Escanee este código QR para acceder a más idiomas.
Digitalize este código QR para obter mais idiomas.

Please read the Quick Start Guide
on the back for first time use

